


TRANSACTION PROCESSING PORTION


MEMBER STORE TERMINAL REGISTRATION PORTION


MEMBER STORE TERMINAL INFORMATION DATABASE

TRANSACTION HISTORY DATABASE


(b) MEMBER STORE N-1MEMBER STORE N MEMBER STORE N+1MEMBER STORE ID: 0 0 0 0 1 MEMBER STORE INFORMATION NUMBER OF : 10 **TERMINALS** INITIAL REGISTERED: * * * * * 62 OPERATIONAL PW : ★★★★★ : 2367A SERIAL ID TERMINAL INFORMATION TERMINAL ID : 0 1 **HARDWARE** : ABC123 **INFORMATION** TRANSACTION : AVAILABLE **STATUS** INFORMATION TERMINAL


















Fig. 11

(a) 70

INSTALLATION WILL BE STARTED. PLEASE INPUT MEMBER STORE ID AND INITIAL REGISTRATION PASSWORD. *√* 71 0 0 0 0 0 1 MEMBER STORE ID 72 **PASSWORD** ΟK **CANCEL** ~ 76 **~** 74

(b) , 78 INITIAL PASSWORD IS INCORRECT. PLEASE START AGAIN FROM THE BEGINNING. Fig.12 (a)



(b)

OPERATIONAL PASSWORD IS INCORRECT.

~ ° * **>**